

## Mode Switch Wiring Reference

For Main & VCT Electric Ovens Only

### Inputs:

- Terminal 5 - L2 from Selector Switch Terminal 1 (Bake Elements)
- Terminal 2 - L2 from Selector Switch Terminal 2 (CT Fan Motor)

### Outputs:

- Terminal 1 - CT Fan Motor
- Terminal 3 - OPEN LINE
- Terminal 4 - Static Bake Elements / Static Contactor Relay A1
- Terminal 6 - CT Bake Elements / CT Contactor Relay A1

